## DESCRIPTION

GenTite Peel & Stick Corners (White) are composed of uncured white EPDM laminated to a cured Butyl based adhesive tape. GenTite Peel & Stick Corners are specifically designed to be used in roofing applications for flashing inside and outside corners. It is not to be used as T-Joint Covers.

## INSTALLATION

Refer to current GenTite Application Instructions for additional application instructions.

### A. Outside Corners

1. Stir GenTite All Purpose Primer thoroughly before using. **DO NOT THIN!** Using a scrub handle and pad, apply and even coat of All Purpose Primer to the cleaned areas of the membrane. Avoid globs and puddles. Allow to dry completely to a dry finger touch.
2. Fold the Peel & Stick Corner in half with the perforated edge of the release paper on the bottom.
3. Remove the upper half of the release paper from the corner. Center the corner against the vertical flashing. Place the release paper between the folded flashing.
4. Starting from the center, form the Peel & Stick Corner around the corner.
5. Remove the release paper from the Peel & Stick Corner. Roll down the flashing forming it tightly into the angle changes first.
6. Mold the flashing onto the roofing surface, working the material from the center to the outside edges.
7. With a Teflon coated or hard rubber roller, hand-roll the entire Peel & Stick Corner.
8. Apply a continuous "high profile" bead of Edge Caulk (White) around the corner and 3" (76 mm) onto T-Joints created by flashing seams.

### B. Inside Corners

1. Stir GenTite All Purpose Primer thoroughly before using. DO NOT THIN! Using a scrub handle and pad, apply and even coat of All Purpose Primer to the cleaned areas of the membrane. Avoid globs and puddles. Allow to dry completely to a dry finger touch.
2. Fold the Peel & Stick Corner in half with the perforated edge of the release paper on the bottom. Fold the Corner in half again forming a ¼ circle.
3. Remove the release paper from the outside of the folded corner.
4. With the short side folded down, place the folded corner flashing ¼" (6 mm) from the wall.
5. Press the flashing tightly into the 90º angle. Unfold the corner.
6. Remove the rest of the release paper from the corner. Mold the corner flashing tightly into the remaining angles, forming a pig-ear on the wall opposite of the vertical seam.
7. Stir GenTite All Purpose Primer thoroughly before using. **DO NOT THIN!** Using a paint brush or roller 3" (76 mm) wide, apply an even coat of All Purpose Primer to the cleaned areas of the membrane. Avoid globs and puddles. Allow to dry completely to a dry finger touch.
8. Mold the pig-ear tight into the corner and to the wall opposite the vertical seam.
9. With a Teflon coated or hard rubber roller, hand-roll the entire Peel & Stick Corner.
10. Apply a continuous "high profile" bead of Edge Caulk (White)) around the corner and 3" (76 mm) onto T-Joints created by flashing seams.

## PRODUCT DATA

| SIZE | QUANTITY | PRODUCT # |
|---|---|---|
| 8.5" (216 mm) Diameter | 20 per Carton | W59GT30100 |

## STORAGE

Store in original unopened container indoors at temperatures between 60 °F (16 °C) and 80 °F (27 °C). Do not store on roof in direct sunlight or at temperatures above 100 °F (38 °C). When exposed to lower temperatures, restore to room temperature prior to use.

## SHELF LIFE

6 months; shelf life will be shortened if exposed to elevated temperatures.

## PRECAUTIONARY DATA

- Refer to Safety Data Sheet (SDS) prior to use.
- Take care when moving, transporting, and handling, etc., to avoid sources of punctures and physical damage.

## TYPICAL PROPERTIES

| FLASHING | TYPICAL VALUES |
|---|---|
| Base | EPDM |
| Color | White |
| Cured State | Semi-cured |
| Size | 8.5" (216 mm) Diameter |
| Thickness (Flashing) | 0.065" ± 0.005" (1.59 mm ± 0.13 mm) |
| TAPE | TYPICAL VALUES |
| Color | White |
| Base | Butyl |
| Solids | 100% |
| Cure State | Cured |
| Thickness | 0.025" ± 0.005" (0.64 mm ± 0.13 mm) |

## LEED INFORMATION

| Recycled Content | |
|---|---|
| Post-Consumer | 0% |
| Post Industrial | 0% |